

KLR650

Homepage

Contact Me

You must remove the "REMOVE-THIS" in my email address for it to work.

This is a hobby website dedicated to the Kawasaki KLR650 motorcycle. I make no claim concerning the accuracy of the procedures, nor do I guarantee the success of any work done using them. All users of the material found here are advised that there is no real or implied warranty associated in any way with the website content, and that all content available here is for use at your own risk.

Copyright © 2001 Mark's KLR Pages

All Rights Reserved

No copying or other redistribution by any method will be permitted without my express written permission.

Links

Miscellaneous Info

D.I.Y. Tips

Grease 101

Technical Articles

A1 Brochure

Conversions

KLR650 FAQ

Painting Plastic

Forms

Maintenance Log

Shim Record Chart

Pictures

Corbin Saddle

Procedures in PDF

12v Waterproof Outlet

## RAIN T-MOD / CARB VENTING

### Required for installation:

8 and 10mm socket  
Philips head screwdrivers

A complete kit for this is available from Arrowhead Motorsports

### NOTE:

"Left" and "right" are described from the saddle position of the motorcycle.

**CAUTION:** Failure to follow installations can result in damage to motorcycle or accessories.

**WARNING:** Failure to follow installations could result in injury or death to operator and/or passenger or others.

1. Place motorcycle on solid, level ground on centerstand if so equipped.
2. Remove the right and left side covers, seat, gas tank and vent lines, "mark the vent line for reassembly."
3. On the top left side of the carburetor you will find the carburetor vent line, it's next to the choke cable. See image below:

Acerbis Disk Installation

Balancer Adjustment

Brake Pads

Cam Chain Timing

Carb Air Mixture

Carb Rain T-Mod

Decalifornication

Doohickey Upgrade

Easy Lift

Fork Oil Change

Horn Upgrade

Hydraulic Clutch

JC Whitney Trunk

Maier Woods Pro

Mirror Mount Repair

Oil Screen Cleaning

TIME-SERT

Radiator Cooling Mod



4. Slide the vent line off the connector and make a cut about 1 ½" from the end.

5. Push that 1 ½" end onto the end of the T fitting, and the remaining vent line onto the T fitting end so it is pointing down.

6. Run the new vent line up under the gas tank mount off to the left side on the frame and along the top of the air box. See image below:



Ramp Loading
Safety Switch Bypass
Shark Fin Installation
Shim Storage Box
Shim Value Table
SuperBrace
Swingarm Maint
Torque Values
Tube Valve Tools
Valve Adjustment
Vista-Cruise Lock
Water Pump Seals
Wheel Alignment

7. Replace the right and left side covers, seat, gas tank and vent lines.